



- 1) To operate Slap Vise, set workpiece against movable jaw and "SLAP-CLOSED." Workpiece now clamped firmly in vise both hands are free, ready for job.
- 2 To release, "SLAP-OPEN." Simple, easy and quick!



*This is an original design - This SLAP-VISE® can be obtained Nowhere Else but:

SPRUNGER CORPORATION

P.O. Box 1621 Elkhart, Indiana 46515